

Dura-Post™ & Dura-Post SX™ Soil Anchor Installation Instructions

Caution: Always wear protective clothing and personal protective equipment (PPE) such as eye protection, work gloves, and steel toe work boots while doing the following work.

 Check that you have all parts necessary for the installation. You should have post(s), soil anchor(s) with one bolt and one nut for each. You will also need a Dura-Post™ drive tool.







- 2. Locate and mark Dura-Post location(s).
- 3. Position the anchor so that when installed, the bolt will be perpendicular to the traffic direction.
- 4. Keep the anchor vertical when driving it into the ground. This will insure that the post will be vertical.

5. Drive the anchor into the ground until the holes are 1/4" above the ground.





6. Insert the post and align the holes in post with the holes in the anchor. Use a bolt and lock nut to secure the post to the anchor.



BOLT & LOCK NUT

REV: A 05/02/09 Part No. 2750097-0000