



Dura-Post™ & Dura-Post SX™ Surface Mount Epoxy Kit Installation Instructions

For Installation on Asphalt or Concrete

Caution: Always wear protective clothing and personal protective equipment (PPE) such as eye protection, work gloves, and steel toe work boots while doing the following work.

1. Check that you have all parts necessary for the installation. You should have post(s), surface mount base(s) and epoxy kit(s) (One epoxy kit per base).



2. Locate and mark Dura-Post location(s). A clean, dry surface is required.
3. Mix epoxy kit (part no. SHEPX-13--KI) 5 oz Part "A" and 5 oz Part "B".

Note: Do not apply the epoxy when the ambient temperature is below 41°F (5°C) or above 104°F (40°C). When the epoxy is 41°F (5°C) to 60°F (15°C) it will be easier to work with if warmed to approximately 80°F (26°C).



4. Apply epoxy evenly to the bottom of the base; including the middle section.



5. Press the base down firmly on the road surface until epoxy appears around the edge. The arrow must face traffic.



6. Allow to cure before installing post.
One hour @ 80°F
Longer in colder weather.
7. Insert the post and drive the securing pin in place with a hammer. To remove the post, use a drift pin to remove the securing pin, then lift the post from the base.

